

Central WHOLESALE, Inc.

HARDWARE / PLUMBING / ELECTRICAL / JANITORIAL

KITCHENS / COMPLETE RENOVATIONS / HVAC

Lock Services

Quality Work by an Experienced Team

A full range of key pinning services at excellent rates and a fast turnaround. Our H.P.C. computerized key system eliminates duplicates by tracking key pinning sequences.



Have a large job? We offer on-site lock work.

Code Keying System

Our staff will generate

and maintain computerized reports that provide assurance that you receive the proper lock pinning sequences for years to come.

We will evaluate

your Master Key to avoid future lock and safety problems.

Most existing

locks can be rekeyed and converted to the code keying system.

Master keys and resident

keys will be cut within .0005 of an inch of factory specifications, and all locks will be keyed to each manufacturer's depth space data.

Lockwork Specialties

11015 KEY CUT, SINGLE

Key cut for regular single key.

22120 KEY CUT, ORIGINAL KEY

Key cut using factory OEM key blank. Also for HPC system.

15143 MASTER KEYING

For new locks keyed differently and to be keyed to customer's master key (must have Master Key on file or bring one to put on file).

11000 REKEY MASTER

Old locks to be rekeyed and master keyed to customer's master key (must have Master Key on file).

10975 NEW LOCKS REKEYED WITH NO KEYS

Locks to be rekeyed to one particular key. Please notify the customer service rep to add a comment line on which key they want locks keyed to. No extra copies provided.

18743 KEY ALIKE

All locks to be keyed to the same key. CWI provides copies of keys. Please notify the customer service rep to add a comment line on how many copies of keys are needed.

11003 KEY IN PAIRS

Two locks to be keyed to the same key (top & bottom locks, two top locks, or two bottom locks in pairs).

11020 KEY IN PAIRS/MASTER

Two locks to be keyed to the same key and also keyed to the master key (top and bottom locks in pairs or two top locks in pairs). Same as 11003 but with mastering.

69857 LOCK WORK/REKEY OLD LOCK

Old locks to be rekeyed with no master key.

21411 LOCK WORK: REPAIR KEY MACHINE

CWI will repair and realign key machines, replace cutter and brush, etc. Call for estimate.

Baltimore (410) 813-2885 • Washington, D.C. (301) 419-2900 CALL: (800) 935-2947 FAX: (800) 935-2735

Richmond / Tidewater / North Carolina / Charlottesville CALL: (800) 935-2947

NY / NJ / PA / DE Regional Areas CALL: (800) 275-8475 FAX: (800) 935-6539

visit us on the web @ www.cwip.com



En Español
(866) 935-2947